



Pontiac GTO (04-06) Shrader Rear Seat Delete

Installation Instructions

NOTE: This product is not to be used as a replacement seat. It is not safe for passengers to ride on the panel.

Removal of factory seats:

- Remove lower seat cushion.
- To remove the back section, unbolt the two 13mm bolts at the bottom of the unit. These are the only 2 bolts.
- The top of the unit is on a hanger. Lift the whole unit upwards while pulling outwards. Remove from car.
- Fold the sound deadening material down so that it's all in the floor pan (if not, it will interfere with mounting)
- Remove the center seatbelt connectors (two 19mm bolts)

Installation of new Rear Seat Delete kit

1. Install supplied plastic brackets as seen in the photo using existing factory threaded holes and the 2 supplied metric bolts/washers.
2. Place lower RSD panel in car. Edges will go slightly under the side panels.
3. **Fasteners.** There are 4 large plastic push-pin clips included with the kit. **Only use 2 of the clips (for now)** in the **CENTER** two holes to hold the lower section. Do not install clips on the outside holes yet.



4. Place back section of RSD in car. Push it all the way back till it's flat with the back wall. Now you can install **the other 2 push-pins** at each lower corner, using the pre-drilled holes through the carpet.



5. ← **SIDE PANELS.** Included with your kit are 2 ABS Plastic side panels to cover the holes on the lower panel.

6. Hold each side panel perfectly in place, resting on top of the carpeted lower panel, and drill a 11/64" hole (3/16" max) through the GTO's interior panel. This will be out of sight should you ever need to re-install the seats.

7. Use the provided small plastic push-pins to secure the panel.

8. **SEATBELTS.** The remaining seatbelts provide a natural cover over the large holes left behind in your side panel →

